



KERN & Sohn GmbH

Ziegelei 1

D-72336 Balingen

E-Mail: info@kern-sohn.com

Tel: +49-[0]7433- 9933-0

Fax: +49-[0]7433-9933-149

Internet: www.kern-sohn.com

Reference manual

KERN Communications Protocol (KCP)

KERN KCP

KCP versions: 1.1.0

Manual version 1.3.0 (2018-02)

GB



KERN KCP

Reference manual

KERN Communications Protocol (KCP)

Table of contents

1	BRIEF OUTLINE	3
1.1	Default interface communication parameters	3
1.2	Basic command and response format	3
1.3	Language conventions	3
1.4	Overview of basic commands	4
2	GENERAL	5
2.1	KCP Version	5
2.2	KCP Command Levels	5
2.3	Conventions in this manual	5
2.4	Default communication parameters	5
2.4.1	RS-232 / RS-485	5
2.5	Protocol structure	6
2.5.1	Encoding	6
2.5.2	Case sensitiveness	6
2.5.3	Commands	6
2.5.4	Responses	6
2.5.5	Examples	6
2.6	Command queue and timing	7
2.6.1	Command queue / sequence	7
2.6.2	Timeouts	7
2.7	Units	7
2.8	Message codes / Error codes	7
3	KCP COMMANDS - LEVEL 0 (CORE COMMANDS)	8
4	KCP COMMANDS - LEVEL 1 (BASIC MEASUREMENT)	21
5	KCP COMMANDS - LEVEL 2 (MODEL-SPECIFIC FEATURES)	34
6	KCP COMMANDS – EXTERNAL TERMINAL (ETL)	39
7	KCP COMMANDS FOR DIGITAL PLATFORMS	55
8	COMMAND INDEX	64

1 Brief outline

The KERN Communications Protocol (KCP) is a standardized interface command set for KERN balances and other instruments, which allows retrieving and controlling all relevant functions and functions of the device. KERN instruments featuring KCP are thus easily integrated with computers, industrial controllers and other digital systems.

This section gives an overview over the general command and response structure and lists the few basic commands required to handle the vast majority of applications.

1.1 Default interface communication parameters

By default, each KCP device comes preset to the following communication parameters. The applicable parameters depend on the type of communication interface:

Interfaces	Parameters			
RS-232 / RS-485 / Bluetooth SPP	Baud rate:	9600 baud/s	Data bits:	8 bits
	Parity:	none	Stop bits:	1 bit

1.2 Basic command and response format

KCP is based on simple ASCII-encoded text commands and responses. Every interaction consists of a command, possibly with arguments separated by spaces (symbol `␣`) and terminated by Windows-style newline characters (`<CR><LF>`):

Command		Arguments					Terminator	
<code><cmd></code>	<code>␣</code>	<code><arg1></code>	<code>␣</code>	<code><arg2></code>	<code>␣</code>	<code><arg3></code>	<code>...</code>	<code><CR></code> <code><LF></code>

Correctly formatted commands are answered with a response containing the requested data including or following a confirmation of the following form:

Response		Status		Data	Terminator	
<code><cmd></code>	<code>␣</code>	A = accepted / acknowledge L = logical error / invalid parameter I = internal / technical error	<code>␣</code>	<i>command specific</i>	<code><CR></code>	<code><LF></code>
ES		Erroneous syntax or unknown command			<code><CR></code>	<code><LF></code>

Example: Command “Set indication unit to grams (g)” with response “accepted”

Command:	U	␣	g	<CR>	<LF>	→	Response:	U	␣	A	<CR>	<LF>
dec:	85	32	103	13	10		dec:	85	32	65	13	10
hex:	55	20	67	0D	0A		hex:	55	20	41	0D	0A

Example: Command “Set indication unit to invalid unit” with response “logical error”

Command:	U	␣	X	<CR>	<LF>	→	Response:	U	␣	L	<CR>	<LF>
dec:	85	32	88	13	10		dec:	85	32	76	13	10
hex:	55	20	58	0D	0A		hex:	55	20	4C	0D	0A

Example: Invalid command

Command:	U	␣	g	<CR>	<LF>	→	Response:	ES	<CR>	<LF>
dec:	85	32	103	13	10		dec:	69 83	13	10
hex:	55	20	67	0D	0A		hex:	45 53	0D	0A

1.3 Language conventions

Throughout this manual, the following conventions are used for command and response syntax:

<code>␣</code>	Space symbol (dec 32, hex 20)
↓	Commands sent to the balance / measurement device.
↑	Responses of the balance / measurement device

1.4 Overview of basic commands

	Request stable indication (weighing or measured value) in the host unit (by default the current indication unit). Waits until indication fulfills the “stable” condition or until configured timeout is reached.	
↓	S	
↑	S_S_____100.00_g S_S_____ -100.00_g S_S_____1152.05_kg S_I S_+ or S_-	Indication value is right aligned, 10 characters. Decimal sign is a point. The minus sign immediately precedes the numerical value – without leading zero. On multi-range devices, hidden trailing decimals are shown as spaces. Status “S” = current indication is stable Status “D” = current indication is unstable / dynamic In menu, currently executing another command or timeout reached. Overload or underload

	Request immediate indication in the host unit (by default the current indication unit) Immediately sends the current indication without waiting for stable conditions.	
↓	SI	
↑	SI_S_____100.00_g SI_D_____99.98_g SI_I SI_+ or S_-	<i>see description of command “S”</i> In menu, currently executing another command or timeout reached. Overload or underload

	Zero indication	Tare indication	
↓	Z	T	
↑	Z_A Z_I Z_+ or Z_-	T_A T_I T_+ or T_-	Zeroing/taring successful. In menu, currently executing another command or timeout reached. Overload or underload; or zero range exceeded

	Query or set display and host unit		
↓	U	Query current display unit	
↑	U_A<unit>	Current display unit is <unit>	
↓	U_<unit>	Set current display and host unit.	Units: g,kg,mg, lb,pcs,%, N,kN,TF,KLBF,...
↑	U_A U_I	Unit successfully set Invalid unit.	

	Set mode of indication (Peak or track mode)	
↓	SIM	Query current mode of indication
↑	SIM_A<mode>	Current mode of indication is <mode>
↓	SIM_<mode>	Set current mode of indication and reset the current peak value. <mode> is one of the following: • T = Track mode (indicate the current measurand) • P = Peak mode (only indicate the largest value +/-) • P+ = Peak positive mode (only indicate the largest pos. value) • P- = Peak negative mode (only indicate the largest neg. value)
↑	SIM_A SIM_I	Mode successfully set, current peak value is zero. Invalid <mode>

	Read measurement memory / reports Sends all available recorded data in a unspecified tabular form (separated by spaces)	
↓	SMEM	
↑	SMEM_A_START	Command understood, next lines will be the data in tabular form
	<header line>	Number Date Time Mode Indication
	<data line 1>	1 2016-01-13 12:34:56 T 12.3456 N
	<data line 2>	2 2016-02-22 12:37:15 P+ 12.3456 kN
	<data line 3>	3 2016-03-31 12:39:41 P- -1234.56 N
	SMEM_A_END	End of data

2 General

2.1 KCP Version

The KCP protocol is continuously being improved. With each new version, the KCP protocol version number is incremented. The number of the KCP version implemented in your particular device can be requested using the `11` command.

Please make sure that you use the correct version of the KCP manual description (this document) for your device. If a command is only available in certain KCP versions, this will be mentioned in the section of the respective command.

2.2 KCP Command Levels

The KCP protocol commands are grouped in multiple levels. While Level 0 and Level 1 are available for all KCP devices, other levels may only be available with certain devices. Please refer to the individual chapter of each level for further details.

It is advised that you try to limit yourself to the lowest level of commands, that you can achieve your goals with. This allows you to connect a larger variety of KCP devices to your software without modifications.

2.3 Conventions in this manual

Throughout this manual, the following conventions are used for command and response syntax:

<code> </code>	Space symbol (dec 32, hex 20)
<code>↓</code>	Commands sent to the balance / measurement device.
<code>↑</code>	Responses of the balance / measurement device
<code>«param»</code>	Parameter name, the brackets (<code>«</code> and <code>»</code>) are not to be sent
<code>[]</code>	Optional parameter / expression

2.4 Default communication parameters

By default, each KCP device comes preset to certain communication parameters. The applicable parameters depend on the type of communication interface and are listed in the following paragraphs.

2.4.1 RS-232 / RS-485

Baud rate: 9600 baud/s

Data bits: 8 bits

Parity: none

Stop bits: 1 bit

2.5 Protocol structure

KCP is based on simple ASCII-encoded text commands and responses.

2.5.1 Encoding

All characters and digits are encoded in ASCII – if not specified otherwise.

2.5.2 Case sensitiveness

The protocol is case sensitive. Commands and arguments should be written as described in this manual.

2.5.3 Commands

Every interaction consists of a command, possibly with arguments separated by spaces (symbol `␣`) and terminated by Windows-style newline characters (`<CR><LF>`):

Command		Arguments					Terminator	
<code><cmd></code>	<code>␣</code>	<code><arg1></code>	<code>␣</code>	<code><arg2></code>	<code>␣</code>	<code><arg3></code>	<code>...</code>	<code><CR></code> <code><LF></code>

Commands should only be sent in uppercase letters.

2.5.4 Responses

Correctly formatted commands are answered with a response containing the requested data including or following a confirmation of the following form:

Response		Status		Data	Terminator	
<code><cmd></code>	<code>␣</code>	A = accepted / acknowledge L = logical error / invalid parameter I = internal / technical error	<code>␣</code>	<i>command specific</i>	<code><CR></code>	<code><LF></code>
ES		Erroneous syntax or unknown command			<code><CR></code>	<code><LF></code>

For commands that only execute actions on the device and do not return information required in your application, you can ignore the responses. However, to increase the reliability of your software, it is a good practice to read and evaluate the responses and act accordingly upon errors.

2.5.5 Examples

The following examples show some very basic interactions using the KCP protocol.

Example: Command “Set indication unit to grams (g)” with response “accepted”

Command:	U	␣	g	<CR>	<LF>	→	Response:	U	␣	A	<CR>	<LF>
dec:	85	32	103	13	10		dec:	85	32	65	13	10
hex:	55	20	67	0D	0A		hex:	55	20	41	0D	0A

Example: Command “Set indication unit to invalid unit” with response “logical error”

Command:	U	␣	X	<CR>	<LF>	→	Response:	U	␣	L	<CR>	<LF>
dec:	85	32	88	13	10		dec:	85	32	76	13	10
hex:	55	20	58	0D	0A		hex:	55	20	4C	0D	0A

Example: Invalid command

Command:	U	␣	g	<CR>	<LF>	→	Response:	ES	<CR>	<LF>
dec:	85	32	103	13	10		dec:	69 83	13	10
hex:	55	20	67	0D	0A		hex:	45 53	0D	0A

2.6 Command queue and timing

2.6.1 Command queue / sequence

Ideally, the balance queues the data stream it receives and handles one command after the other. When this queue would overflow, the handshake mechanism of the underlying communication interface (e.g. RS-232 CTS/RTS or XON/XOFF handshake) prevents further data packages from the host computer. This allows the host computer to send whole scripts of commands to the balance.

Depending on the balance type (processor capabilities), this may not be possible. For maximum reliability, wait for the answer of a command before sending the next command – otherwise, for some balances, data could be corrupted or commands be missed.

2.6.2 Timeouts

There is no timeout between each character on a single command line (up to and including CR LF). An incomplete line will remain in the balance buffer without timeout until the line is completed. If the balance receive buffer is overflowing because there was no line end, the whole buffer is cleared.

This allows commands to be entered over a terminal software by a human user (one character at a time).

2.7 Units

All commands and responses in the KCP protocol use the following unit symbols:

Name	Symbol	Comment
Kilogram	kg	- no comment -
Ton	t	= 1000 kg
Gram	g	= 0.001 kg
Milligram	mg	= 0.000001 kg
Pound	lb	= 0.45359237 kg (lb. av. – Avoirdupois)
Pieces	pcs	requires piece weight
Percent	%	requires weight of 100%
Newton	N	Unit of force (where applicable)
Kilonewton	kN	= 1000 N
Ton-force	tf	= 9.80665 kN (weight of one ton due to standard gravity)
Pound-force	lbf / klbf	= 4.4482216152605 N (weight of one pound to standard gravity)

2.8 Message codes / Error codes

The following codes are used for errors and messages. In the protocol, the code number may be prefixed, e.g. "E1000".

Code	Comment

3 KCP commands - Level 0 (core commands)

The commands from Level 0 offer the very basic functions available for every KCP device.

@	Cancel
I0	List all implemented KCP commands
I1	Query KCP level and KCP versions
I2	Query device information (type, capacity)
I3	Query device software version
I4	Query serial number
I5	Query SW-Identification number
S	Send stable indication (weight value / measured value)
SI	Send current indication immediately
SIR	Send current indication immediately and repeat
Z	Zero
ZI	Zero immediately

@ – Cancel

Description

@ can be used to achieve the same effect as disconnecting and reconnecting the power supply, which empties the volatile memories. The purpose of this command is to initiate a command sequence.

Syntax

Command

@	Resets the device to the condition found after switching on, but without a zero setting being performed.
---	--

Responses

I4_A_ "«SNR»"	Serial number is emitted; the device is ready for operation.
---------------	--

Comments

- All commands awaiting responses are cancelled.
- If the device is on standby, it is switched on.
- The cancel command is always executed.
- The emitted serial number corresponds to the serial number of the terminal (if one is present), see [I4].

Examples

↓	@	Cancel
↑	I4_A_ "B021002593"	Device is "reset", its serial number is B021002593

See also

→	I4 – Query serial number
---	--------------------------

All level 0 commands are listed in alphabetical order before all commands of level 1 etc.

Command

Responses

Parameters / Return values

Comments

- If a terminal and a weigh module, weighing platform are being used, the command list of the terminal is output. If only a weigh module, platform is being used, the command list of the weigh module, platform is shown.
- If `IO` lists commands that cannot be found in the manual, these are reserved commands "for internal use" or "for future use", and should not be used or altered in any way.

↓	I0	Send list of commands
↑	I0_B_0_"I0"	Level 0 command I0 implemented
↑	I0_B...	...
↑	I0_B_0_"@"	Level 0 command @ (cancel) implemented
↑	I0_B_1_"D"	Level 0 command D implemented
↑	I0_B...	...
↑	I0_A_3_"SM4"	Level 3 command SM4 implemented

➔ @ - cancel

I1 – Query KCP level and KCP versions

Description

Query KCP level and versions.

Syntax

Command

I1	Query KCP level and KCP versions.
----	-----------------------------------

Responses

I1_A_“«Level»”_“«V0»”_“«V1»”_“«V2»”_“«V3»”	Current KCP level and KCP versions
I1_I	Command understood but currently not executable

Parameters / Return values

Name	Type	Values	Meaning
Level	string	0	KCP level 0
		01	KCP level 0 and 1
		03	KCP level 0 and 3
		013	KCP level 0, 1 and 3
		...	...
V0..V3	string		KCP versions of the related level (0 to 3)

Examples

↓	I1	Query the current KCP level and version
↑	I1_A_“123”_“2.00”_“2.20”_“1.00”_“1.50”	Level 0-3 is implemented and the according version numbers are shown

I2, IBMT – Query device information (type, capacity)

Description

Use I2 to query information about the device (e.g. type and weighing capacity). The response is output as a whole string.

Syntax

Command

I2	Query of the device .
----	-----------------------

Responses

I2_A_ "«Type»_«Capacity»_«Unit»"	Device/instrument type and capacity.
I2_I	Command understood but currently not executable (device is currently executing another command, e.g. taring).

Parameters / Return values

Name	Type	Values	Meaning
Type	string		Type of device / instrument
Capacity	string		Capacity of device / instrument
Unit	string		Weight unit

Comments

- With multi-range devices, the last decimal place is available only in the finer ranges.
- The number of characters of "text" depends on the device type and capacity.

Examples

↓	I2	Query of the device data
↑	I2_A_ "GAT_6K-4_6000.00_g"	Device type and capacity

I3 – Query device software version

Description

Provides the device software version.

Syntax

Command

I3	Query of the device software version.
----	---------------------------------------

Responses

I3_A_«Software»_«TNR»	Device software version and type number.
I3_I	Command understood but currently not executable (device is currently executing another command, e.g. taring).

Parameters / Return values

Name	Type	Values	Meaning
Software	string		Software (Firmware) version
TNR	string		Type number

Comments

- Only the software version of the terminal software is issued.
- If no terminal is present, the bridge software is issued instead.

Examples

↓	I3	Query of the Software version number(s) and type definition number
↑	I3_A_“4.10_10.142”	4 .10: Software version number 10.142: Type number

I4 , IBIS – Query serial number

Description

Use I4 to query the serial number of the device. In the case of devices, the serial number of the terminal is output.

Syntax

Command

I4	Query of the serial number.
----	-----------------------------

Responses

I4_A_«SNR»	Serial number.
I4_I	Command not understood, not executable at present Command understood but currently not executable (device is currently executing another command, e.g. initial zero setting).

Parameters / Return values

Name	Type	Values	Meaning
SNR	string		Serial number

Comments

- The serial number agrees with that on the model plate and is different for every device.
- The serial number can be used, for example, as a device address in a network solution.
- The device response to I4 appears unsolicited after switching on and after the cancel command @.
- Only the serial number of the terminal is issued.
- If no terminal is present, the serial number of the bridge is issued instead.

Examples

↓	I4	Query of serial number
↑	I4_A_«WX1712345»	The serial number is: WX1712345

See also

→	@ - cancel
---	------------

I5 – Query SW-Identification number

Description

Use I5 to query the software identification number.

Syntax

Command

I5	Query of the SW-identification number.
----	--

Responses

I5_A_ "«SWID»"	SW-Identification number with index.
I5_I	Command understood but currently not executable (device is currently executing another command, e.g. taring).

Parameters / Return values

Name	Type	Values	Meaning
SWID	string		SW-Identification number with index.

Comments

- Only the software identification number of the terminal is issued.
- If no terminal is present, the software identification number of the bridge is issued instead.

Examples

↓	I5	Query of the SW-identification number
↑	I5_A_ "V1.02"	V1.02: SW-identification number with index

S – Send stable weight value

Description

Use *S* to send a stable weight value, along with the unit.

Syntax

Command

<i>S</i>	Send the current stable net weight value.
----------	---

Responses

<i>S_S_«WeightValue»_«Unit»</i>	Current stable weight value in unit set.
<i>S_I</i>	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
<i>S_L</i>	Command understood but not executable (incorrect parameter).
<i>S_+</i>	Device in overload range.
<i>S_-</i>	Device in underload range.
<i>S_S_«ErrorCode»</i>	Code of error occurred

Parameters / Return values

Name	Type	Values	Meaning
WeightValue	float		Weight value
Unit	string		Currently displayed unit
ErrorCode	string		Code of error occurred

Comments

- The duration of the timeout depends on the device type.
- The weight value is formatted as a right aligned string with 10 characters including the decimal point.
- Preceding zeros are not shown except for the zero to the left of the decimal point.
- For multi-range or floating range balances, the decimal places at the end that are not displayed (in higher ranges) are shown as spaces.

Examples

↓	<i>S</i>	Send a stable weight value
↑	<i>S_S_100.00_g</i>	The current, stable ("S") weight value is 100.00 g
↑	<i>S_S_200.00_g</i> <i>S_S_200.0_g</i> (d = 0.01/0.1g)	In a higher range (for multi/floating-range balances), the last digit disappears and is replaced with a space.
	<i>S_S_200.0_g</i> <i>S_S_200. _g</i> (d = 0.1/1g)	
↑	<i>S_S_200. _g</i>	Theoretically, even two spaces could be missing with d=0.01/0.1/1g.
↑	<i>S_S_10000_g</i>	When there is no decimal point, the value is still right aligned as described above.

SI – Send weight value immediately

Description

Use **SI** to immediately send the current weight value, along with the unit.

Syntax

Command

SI	Send the current net weight value, irrespective of device stability.
----	--

Responses

S_S_«WeightValue»_«Unit»	Stable weight value in unit set
S_D_«WeightValue»_«Unit»	Non-stable (dynamic) weight value in unit set
S_I	Command understood but currently not executable (device is currently executing another command, e.g. taring).
S_L	Command understood but not executable (incorrect parameter).
S_+	Device in overload range.
S_-	Device in underload range.
S_S_«ErrorCode»	Code of error occurred

Parameters / Return values

Name	Type	Values	Meaning
WeightValue	float		Weight value
Unit	string		Currently displayed unit
ErrorCode	string		Code of error occurred

Comments

- The device response to the command **SI** is the last internal weight value (stable or dynamic) before receipt of the command **SI**.
- The weight value is formatted as described in the comments of the **S** command.

Examples

↓	SI	Send current weight value
↑	S_D_129.07_g	The weight value is unstable (dynamic, "D") and is currently 129.07 g

SIR – Send weight value immediately and repeat

Description

Use `SIR` to immediately send the current weight value, along with the unit, on a continuous basis.

Syntax

Command

<code>SIR</code>	Send the net weight values repeatedly, irrespective of device stability. The default time between transmissions is device dependent (typically around 15 Hz).
<code>SIR_«TimeMsBetweenTransmissions»</code>	As above, setting the time between transmissions explicitly (in milliseconds).

Responses

<code>S_S_«WeightValue»_«Unit»</code>	Stable weight value in unit set
<code>S_D_«WeightValue»_«Unit»</code>	Non-stable (dynamic) weight value in unit set
<code>S_I</code>	Command understood but currently not executable (device is currently executing another command, e.g. taring).
<code>S_L</code>	Command understood but not executable (incorrect parameter).
<code>S_+</code>	Device in overload range.
<code>S_-</code>	Device in underload range.
<code>S_S_«ErrorCode»</code>	Code of error occurred

Parameters / Return values

Name	Type	Values	Meaning
<code>TimeMsBetweenTransmissions</code>	int		Time in milliseconds between repeated transmissions
<code>WeightValue</code>	float		Weight value
<code>Unit</code>	string		Currently displayed unit
<code>ErrorCode</code>	string		Code of error occurred

Comments

- `SIR` is overwritten by the commands `S`, `SI`, `@` and hardware break and hence cancelled.
- The weight value is formatted as a right aligned string with 10 characters including the decimal point.

Examples

↓	<code>SIR</code>	Send current weight values at intervals
↑	<code>S_D_129.07_g</code>	The device sends stable ("S") or unstable ("D") weight values at intervals
↑	<code>S_D_129.08_g</code>	
↑	<code>S_S_129.09_g</code>	
↑	<code>S_S_129.09_g</code>	
↑	<code>S_D_129.87_g</code>	
↑	<code>S_...</code>	

Z – Zero

Description

Use **Z** to set a new zero; all weight values (including the tare weight) will be measured relative to this zero. After zeroing has taken place, the following values apply: tare weight = 0; net weight (= gross weight) = 0.

Syntax

Command

Z	Zero the device.
----------	------------------

Responses

Z_A	Zero setting successfully performed. Gross, net and tare = 0.
Z_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
Z_+	Upper limit of zero setting range exceeded.
Z_-	Lower limit of zero setting range exceeded.

Comments

- The tare memory is cleared after zero setting.
- The zero point determined during switching on is not influenced by this command, the measurement ranges remain unchanged.
- The duration of the timeout depends on the device type.

Examples

↓	Z	Zero
↑	Z_A	Zero setting performed

ZI – Zero immediately

Description

Use **ZI** to set a new zero immediately, regardless of device stability. All weight values (including the tare weight) will be measured relative to this zero. After zeroing has taken place, the following values apply: tare weight = 0; net weight (= gross weight) = 0.

Syntax

Command

ZI	Zero the device immediately regardless the stability of device..
----	--

Responses

ZI_D	Re-zero performed under non-stable (dynamic) conditions.
ZI_S	Re-zero performed under stable conditions.
ZI_I	Command understood but currently not executable (device is currently executing another command, e.g. taring).
ZI_+	Upper limit of zero setting range exceeded.
ZI_-	Lower limit of zero setting range exceeded.

Comments

- The tare memory is cleared after zero setting.
- This command is not supported by approved devices.
- The zero point determined during switching on is not influenced by this command, the measurement ranges remain unchanged.

Examples

↓	ZI	Zero immediately
↑	ZI_D	Re-zero performed under non-stable (dynamic) conditions

4 KCP commands - Level 1 (basic measurement)

The commands from Level 1 are available for all basic weighing instruments.

D	Display: Write text to display
DW	Display: Show weight
K	Keys: Set configuration
SR	Send weight value on weight change (send and repeat)
T	Tare
TA	Query/preset tare weight value
TAC	Clear tare value
TI	Tare immediately
U	Query or set display and host unit

D – Display: Write text to display

Description

Use **D** to write text to the device display.

Syntax

Command

D_ “« <i>DisplayText</i> »”	Write text into the device display.
------------------------------------	-------------------------------------

Responses

D_A	Command understood and executed successfully: Text appears left-aligned in the device display marked by a symbol, e.g. *.
D_I	Command understood but currently not executable.
D_L	Command understood but not executable (incorrect parameter or device with no display).

Parameters / Return values

Name	Type	Values	Meaning
DisplayText	string		Text on the device display

Comments

- A symbol in the display, e.g. * indicates that the device is not displaying a weight value.
- The maximum number of characters of "text" visible in the display depends on the device type. If the maximum number of characters is exceeded, the text disappears on the right side.
- Quotation marks can be displayed as indicated

Examples

↓	D_ “HELLO”	Write "HELLO" into the device display
↑	D_A	The full text HELLO appears in the device display

↓	D_ “ ”	Clear the device display
↑	D_A	Device display cleared, marked by a symbol, e. g. *

See also

➔	DW – Display: Show weight
---	---------------------------

DW – Display: Show weight

Description

Writes the current weight value to the device display using the set unit. This command is used to reset the display after using the `D` command.

Syntax

Command

DW	Switch the main display to weight mode.
----	---

Responses

DW_A	Command understood and executed successfully: Main display shows the current weight value.
DW_I	Command understood but currently not executable.

Comments

- DW resets the device display following a `[D]` command.

Examples

↓	DW	Switch the main display to weight mode
↑	DW_A	Main display shows the current weight value

See also

➔	D – Display: Write text to display
---	------------------------------------

K – Keys: Set configuration

Description

With the **K** command, the behavior of the terminal keys may be configured: first, the **K** command controls whether a key invokes its corresponding function or not and second, it configures whether an indication of which key has been pressed or released is sent to the host interface or not.

Using this functionality, an application running on a connected system (e.g. a PC or PLC) may make use of the device terminal to interact with the device operator.

Syntax

Command

<code>K_«Mode»</code>	Set configuration.
-----------------------	--------------------

Responses

<code>K_A[_«FunctionID»]</code>	Command understood and executed successfully. Mode 4: Function with «FunctionID» was invoked by pressing the corresponding key and executed successfully.
<code>K_I[_«FunctionID»]</code>	Command understood but currently not executable (device is actually in menu or input mode). Mode 4: Function with «FunctionID» by pressing the corresponding key, but it could not be successfully executed (e.g. calibration was aborted by user or a negative value was tared).
<code>K_L</code>	Command understood but not executable (incorrect or no parameter).

Additional Responses in Mode 3:

<code>K_«EventID»_«KeyID»</code>	Key «KeyID» has issued an «EventID».
----------------------------------	--------------------------------------

Additional Responses in Mode 4:

<code>K_B_«FunctionID»</code>	Function with «FunctionID» was invoked and started; the execution needs time to complete.
-------------------------------	---

Parameters / Return values

Name	Type	Values	Meaning
Mode	integer	1	Functions are executed, no indications are sent (factory setting)
		2	Functions are not executed, no indications are sent
		3	Functions are not executed, indications are sent
		4	Functions are executed, indications are sent
EventID	char	R	Key was pressed and held around 2 seconds
		C	Key was released(after being pressed shortly or for 2 second)
FunctionID	integer	0	Adjustment
		1	Tare
		2	Zero
		3	Data transfer to printing device
		4 ... 6	Reserved for future use
		7	Test
KeyID	integer	1	Home
		2	User profile
		3	Settings
		5	Zero
		7	Transfer
		8	Configure actual applications
		9	Applications

Comments

- K_{-1} is the factory setting (default value).
- K_{-1} active after device switched on and after the cancel command [C].
- Only one K mode is active at one time.

Examples

When a code with a long press is sent, new key commands will not be accepted.

↓	K_{-4}	Set mode 4: when a key is pressed, execute the corresponding function and send the function number as a response
↑	K_{-A}	Command executed successfully
↑	$K_{-B_{-}1}$	The taring function has been started → taring active
↑	$K_{-A_{-}1}$	Taring completed successfully
↑	$K_{-B_{-}1}$	The taring function has been started → taring active
↑	$K_{-I_{-}1}$	Taring not completed successfully, taring aborted (e.g. tried to tare a negative value)

SR – Send weight value on weight change (send and repeat)

Description

Use SR to send the current weight values following a predefined minimum change in weight and on a continuous basis. The weight value is sent, along with the unit.

Command

SR	Send the current stable weight value and then continuously after every weight change. If no preset value is entered, the weight change must be at least 12.5% of the last stable weight value, minimum = 30 digit.
SR_«PresentValue»_«Unit»	Send the current stable weight value and then continuously after every weight change greater or equal to the preset value a non-stable (dynamic) value followed by the next stable value, range = 1 digit to maximal capacity.

Responses

S_S_«WeightValue»_«Unit»	Current, stable weight value in unit set, 1 st weight change.
S_D_«WeightValue»_«Unit»	Dynamic weight value in unit set.
S_S_«WeightValue»_«Unit»	Next stable weight value in unit set.
S_I	Command understood but currently not executable (device is currently executing another command, e.g. zero setting, or timeout as stability was not reached).
S_L	Command understood but not executable (incorrect parameter).
S_+	Device in overload range.
S_-	Device in underload range.
S_S_«ErrorCode»	Code of error occurred

Parameters / Return values

Name	Type	Values	Meaning
WeightValue	float		Weight value
Unit	string		Unit, only available units permitted
ErrorCode	string		Code of error occurred

Comments

- SR is overwritten by the commands S, SI, @ and hardware break and hence cancelled.
- If, following a non-stable (dynamic) weight value, stability has not been reached within the timeout interval, the response S_I is sent and then a non-stable weight value. Timeout then starts again from the beginning.
- The preset value can be entered in any by the device accepted unit.
- The weight value is formatted as a right aligned string with 10 characters including the decimal point.

Examples

↓	SR_10.00_g	Send the current stable weight value followed by every load change of 10 g
↑	S_S_100.00_g	Device stable
↑	S_D_115.23_g	100.00 g loaded
↑	S_S_200.00_g	Device again stable

See also

➔	S - Send stable weight value
➔	SI - Send weight value immediately
➔	SIR - Send weight value immediately and repeat

T – Tare

Description

Use **T** to tare the device. The next stable weight value will be saved in the tare memory.

Command

T	Tare, i.e. store the next stable weight value as a new tare weight value.
---	---

Responses

T_S_«TareWeightValue»_«Unit»	Taring successfully performed. The tare weight value returned corresponds to the weight change on the device in the unit set since the last zero setting.
T_I	Command understood but currently not executable (device is currently executing another command, e.g. zero setting, or timeout as stability was not reached).
T_L	Command understood but not executable (incorrect parameter).
T_+	Upper limit of taring range exceeded.
T_-	Lower limit of taring range exceeded.

Parameters / Return values

Name	Type	Values	Meaning
TareWeightValue	float		Weight value
Unit	string		Currently displayed unit

Comments

- The tare memory is overwritten by the new tare weight value.
- The duration of the timeout depends on the device type.
- Clearing tare memory: See **TAC**.
- The weight value is formatted as a right aligned string with 10 characters including the decimal point.

Examples

↓	T	Tare
↑	T_S_100.00_g	The device is tared and has a value of 100.00 g in the tare memory

See also

➔	TAC - Clear tare value
---	------------------------

TA – Query/preset tare weight value

Description

Use TA to query the current tare value or preset a known tare value.

Command

TA	Query of the current tare weight value (rounded).
TA_«TarePresentValue»_«Unit»	Preset of a tare value.

Responses

TA_A_«TareWeightValue»_«Unit»	Query current tare weight value in tare memory, in unit set.
TA_I	Command understood but currently not executable (device is currently executing another command, e.g. zero setting, or timeout as stability was not reached).
TA_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
TareWeightValue	float		Rounded tare weight value
Unit	string		Currently displayed unit

Comments

- The tare memory will be overwritten by the preset tare weight value.
- The inputted tare value will be automatically rounded by the device to the current readability.
- The taring range is specified to the device type.
- The weight value is formatted as a right aligned string with 10 characters including the decimal point.

Examples

↓	TA_100.00_g	Preset a tare weight of 100 g
↑	TA_A_100.00_g	The device has a value of 100.00 g in the tare memory

See also

➔	TAC - Clear tare value
---	------------------------

TAI – Query/preset tare weight value (internal, not rounded)

Description

Use TAI to query the current, unrounded tare value or preset a known exact tare value.

Command

TAI	Query of the current tare weight value (rounded).
TAI_«TarePresentValue»_«Unit»	Preset of a tare value.

Responses

TAI_A_«TareWeightValue»_«Unit»	Query current tare weight value in tare memory, in unit set.
TAI_I	Command understood but currently not executable (device is currently executing another command, e.g. zero setting, or timeout as stability was not reached).
TAI_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
TareWeightValue	float		Exact tare weight value
Unit	string		Currently displayed unit

Comments

- The tare memory will be overwritten by the preset tare weight value.
- The inputted tare value will **not** be rounded to the current readability.
- The taring range is specified to the device type.

Examples

↓	TAI_100.00_g	Preset a tare weight of 100 g
↑	TAI_A_100.00_g	The device has a value of 100.00 g in the tare memory

See also

➔	TAC - Clear tare value
---	------------------------

TAC – Clear tare value

Description

Use TAC to clear the tare memory.

Command

TAC	Clear tare value.
-----	-------------------

Responses

TAC_A	Tare value cleared, 0 is in the tare memory.
TAC_I	Command understood but currently not executable (device is currently executing another command, e.g. zero setting).
TAC_L	Command understood but not executable (incorrect parameter).

Examples

↓	TAC	Clear tare value
↑	TAC_A	are value cleared, o is in the tare memory

See also

➔	T – Tare
➔	TI – Tare immediately
➔	TA – Query/preset tare weight value
➔	TC – Tare or tare immediately after timeout

TI – Tare immediately

Description

Use **TI** to tare the device immediately and independently of device stability.

Command

TI	Tare immediately, i.e. store the current weight value, which can be stable or non stable (dynamic), as are weight value.
----	--

Responses

TI_S_«TareWeightValue»_«Unit»	Taring performed, stable tare value. The new tare value corresponds to the weight change on the device since the last zero setting.
TI_D_«TareWeightValue»_«Unit»	Taring performed, non-stable (dynamic) tare value.
TI_I	Command understood but currently not executable (device is currently executing another command, e.g. zero setting).
TI_L	Command understood but not executable (e.g. certified version of the device).
TI_+	Upper limit of taring range exceeded.
TI_-	Lower limit of taring range exceeded.

Parameters / Return values

Name	Type	Values	Meaning
TareWeightValue	float		Tare Weight value
Unit	string		Currently displayed unit

Comments

- The tare memory will be overwritten by the new tare weight value.
- After a non-stable (dynamic) stored tare weight value, a stable weight value can be determined. However, the absolute value of the stable weight value determined in this manner is not accurate.
- The taring range is specified to the device type.
- The weight value is formatted as a right aligned string with 10 characters including the decimal point.
- The stored tare weight value is sent in the unit set

Examples

↓	TI	Tare immediately
↑	TI_D_117.57_g	The tare memory holds a non-stable (dynamic) weight value

See also

➔	TAC – Clear tare value
---	------------------------

U – Query / set display and host unit

Description

This command retrieves or sets both the display and the host unit.

The *display unit* is the unit displayed in the display of the indicator.

The *host unit* is the unit used to send weighing values to the *host* (remote device / computer).

Syntax

Command

U	Query the current display unit.
U_«UnitSymbol»	Set the current display and host unit.

Responses

U_A_«UnitSymbol»	Returns the currently set display unit symbol.
U_A	Unit successfully set.
U_I	Unit symbol invalid or required factors not set (see below).

Parameters / Return values

Name	Type	Values	Meaning
UnitSymbol	string	see [Units]	Symbol of the unit to set.

Comments

- For certain units (e.g. percent, pieces, free factor, ...), before using this command, the corresponding factor has to be set using KCP commands or the balance keyboard.

Examples

↓	U	Query unit
↑	U_A_g	The current unit is gram (g).
↑	U_A_kg	The current unit is kilogram (kg).
↓	U_g	Set the units to gram (g).
↑	U_A	The unit is set now.
↓	U_%	Set the unit to percent (%).
↑	U_I	Invalid action, because the weight of 100% was not set before.

5 KCP commands - Level 2 (model-specific features)

The commands from Level 2 are available for certain instruments.
In future versions of KCP, these commands are split into categories.

PCTW Percent weighing: Query/set 100% weight

PW Piece counting: Query/set piece weight

SIM Set mode of indication (Peak or track mode)

SMEM Read measurement memory / reports

PCTW – Percent weighing: Query/set 100% weight

Description

Use this command to set or query the reference value for percent weighing.

Syntax

Command

PCTW	Queries the weight corresponding to 100%.
PCTW_«WeightValue»_«Unit»	Sets the weight corresponding to 100%.

Responses

PCTW_A_«WeightValue»_«Unit»	Current 100% reference weight with unit.
PCTW_A	100% reference weight is set.
PCTW_I	Command understood but currently not executable.
PCTW_L	Command understood but not executable (incorrect weight).

Parameters / Return values

Name	Type	Values	Meaning
WeightValue	float		100% reference weight – numerical value
Unit	string		100% reference weight – unit string

Comments

The balance automatically changes to the percent weighing mode.

Examples

↓	PCTW	
↑	PCTW_A_100.00_g	The current 100% weight value is 100.00 g.
↓	PCTW_100.00_g	Set the current 100% weight value to 100.00 g.
↑	PCTW_A	OK

PW – Piece counting: Query / set piece weight

Description

Use this command to set or query the piece weight value for piece counting.

Syntax

Command

PW	Queries the current piece weight.
PW_«WeightValue»_«Unit»	Sets the current piece weight.

Responses

PW_A_«WeightValue»_«Unit»	Returns the current piece weight.
PW_A	Current piece weight is set.
PW_I	Command understood but currently not executable.
PW_L	Command understood but not executable (incorrect weight).

Parameters / Return values

Name	Type	Values	Meaning
WeightValue	float		Piece weight – numerical value
Unit	string		Piece weight – unit string

Comments

The balance automatically changes to the piece counting mode.

Examples

↓	PW	
↑	PW_A_1.2345_g	The current piece weight is 100.00 g.
↓	PW_1.2345_g	Set the current piece weight to 100.00 g.
↑	PW_A	OK

SIM – Set mode of indication (peak or track mode)

Description

Queries or sets the current mode of indication and resets the current peak value.

Syntax

Command

SIM	Query current mode of indication.
SIM_«Mode»	Set current mode of indication and reset the current peak value.

Responses

SIM_«Mode»	Current mode of indication.
SIM_A	Mode successfully set, current peak value is zero.
SIM_I	Invalid mode.

Parameters / Return values

Name	Type	Values	Meaning
Mode	string	T	Track mode: indicate the current measurand
		P	Peak mode: only indicate the largest value +/-
		P+	Peak positive mode: only indicate the largest pos. value
		P-	Peak negative mode: only indicate the largest neg. value

Examples

↓	SIM	Query current mode of indication.
↑	SIM_T	Current mode of indication is track mode.
↑	SIM_P+	Current mode of indication is peak positive mode.
↓	SIM_P+	Set current mode of indication to peak positive.
↑	SIM_A	OK, peak value reset.
↓	SIM_XYZ	Invalid mode.
↑	SIM_I	Error.

SMEM – Read measurement memory / reports

Description

Sends all available recorded data in a unspecified tabular form (separated by spaces).

Syntax

Command

SMEM	Request recorded data.
------	------------------------

Responses

SMEM_A_START <header line> <data line 1> <data line 2> <data line 3> SMEM_A_END	For better human readability, the data values in the columns are right or left-aligned, depending on the field type. Values/data strings with spaces shall be quoted/escaped as defined.
--	---

Examples

↓	SMEM	
↑	SMEM A START Number Date Time Mode Indication 1 2016-01-13 12:34:56 T 12.3456 N 2 2016-02-22 12:37:15 P+ 12.3456 kN 3 2016-03-31 12:39:41 P- -1234.56 N SMEM A END	

6 KCP commands – External Terminal (ETL)

ETLS – Start continuous status transmission

Description

Starts sending relevant balance status information continuously with a high repetition rate.

Syntax

Command

ETLS[_«On/Off»]	Start/stop status transmission.
-----------------	---------------------------------

Responses

ETLS_A	Acknowledged
	One line with the following information (repeated), separated by spaces:
ETLS_#####	
Nr	Sequential 16bit number, round-robin for hash code, 0 if not used
Hash	Hash code for integrity of this line (0 if not used)
NetInternalValue	Internal net weighing value before rounding, but after all corrections.
NetRoundedValue	Net weighing value rounded to correct digits. Missing trailing digits (multi range balances) are replaced by underscore (_). E##### in case of errors in the weighing system (see <i>Message Codes</i>).
GrossRoundedValue	Gross weighing value rounded to correct digits. Missing trailing digits (multi range balances) are replaced by underscore (_). E##### in case of errors in the weighing system (see <i>Message Codes</i>).
TareRoundedValue	Tare value rounded to correct digits. Missing trailing digits (multi range balances) are replaced by underscore (_). E##### in case of errors in the weighing system (see <i>Message Codes</i>).
Unit	Current display unit.
InsignificantDigits	Number of insignificant digits. Examples: 1 (last digit is insignificant = grey digit) 2 (last two digits are insignificant = grey digits) 3 not possible 12.2340 g
ActiveRangeNo	Number of active range (0 ... n-1)
IndicatorFlags	Encoded as characters 0 S Z N T P C when true, else missing. Meaning: • 0: Zero indicator • C: Internal calibration necessary • N: Net indicator • P: Print allowed • S: Stability indicator • Z: Zero allowed • T: Tare allowed Example: "ST" means stable and tare allowed, zero and print not allowed
DetailStatusCode	Message code for current (most important) status, see <i>Message Codes</i> . Used for current state, like initial zero error, or other errors.

Parameters / Return values

Name	Type	Values	Meaning
On/Off	bool		Enable/disable status transmission

Comments

This command is specifically designed for use with remote display indicators like EasyTouch tablets.

- The sending frequency depends on the balance capabilities, but should be at least 10 Hz for a fast display refresh rate.

Examples

↓	ETLS	Enables the ETL status transmission.
↓	ETLS_1	Enables the ETL status transmission.
↑	ETLS_A ETLS_... ETLS_... ETLS_... ...	Transmission started. Line Another line Another line

TZ – Combined Tare/Zero

Description

Tare or zero the balance, depending on the current load (like a combined tare/zero button).

Syntax

Command

TZ	Tare or zero the balance.
----	---------------------------

Responses

TZ_A_«TareOrZero»[_«TareWeightValue»_«Unit»]	Balance tared or zeroed, depending on current load. If tared, the new tare value is being sent as parameter.
TZ_I	Command understood but currently not executable (device is currently executing another command, e.g. zero setting, or timeout as stability was not reached).
TZ_L	Command understood but not executable (incorrect parameter).
TZ_+	Upper limits exceeded.
TZ_-	Lower limits exceeded.

Parameters / Return values

Name	Type	Values	Meaning
TareOrZero	string	T	Tare operation executed
		Z	Zero operation executed
TareWeightValue	float		Weight value
Unit	string		Currently displayed unit

Examples

↓	TZ	Tare or zero.
↑	TZ_A_Z	Balance zeroed, tare value is cleared.

↓	TZ	Tare or zero.
↑	TA_A_T_____100.00_g	Balance tared, the device has a value of 100.00 g in the tare memory

See also

➔	T - Tare
➔	Z - Zero
➔	TAC - Clear tare value

IBRL / BalanceRangesList – List of balance range information

Description

Describe the command in detail here.

Syntax

Command

IBRL	Describe different variants of the command in this table.
------	---

Responses

IBRL_B_«RangeNr»_«Max»_«Unit»_«d»_«Unit» [_«Min» _«Unit» _«e» _«Unit»] IBRL_B_«RangeNr»_«Max»_«Unit»_«d»_«Unit» [_«Min» _«Unit» _«e» _«Unit»] ... IBRL_A	Current stable weight value in unit actually set under host unit.
IBRL_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
IBRL_L	Command understood but not executable (incorrect parameter).
IBRL_+	Device in overload range.
IBRL_-	Device in underload range.
IBRL_S_«ErrorCode»	Error occurred, see [<i>Specific Error Messages on Weight Response</i>]

Parameters / Return values

Name	Type	Values	Meaning
RangeNr	float	0,1,2,3,...	Number of the range
Max	float		Max (capacity of this range)
d	float		d (readout)
Min	float		Min (minimum verification value)
e	float		e (verification interval)
Unit	string	see <i>Units</i>	Unit for the corresponding value.

IBRT – Query balance ranges type

Description

Query the type of the balance ranges. This defines the way, the balance switches between ranges (if multiple).

Syntax

Command

IBRT	Query balance range type.
------	---------------------------

Responses

IBRT_A_« <i>BalanceRangeType</i> »	Answer with balance range type.
------------------------------------	---------------------------------

Parameters / Return values

Name	Type	Values	Meaning
BalanceRangeType	string	SR	Single range
		MR	Multi range
		FR	Floating range

C3 – Start adjustment with internal weight

Description

You can use C3 to start an internal adjustment procedure.

Syntax

Command

C3	Start the internal adjustment.
----	--------------------------------

First Responses

C3_B	The adjustment procedure has been started. Wait for second response.
C3_I	Adjustment cannot be performed at present as another operation is taking place. No second response follows.
C3_L	Adjustment operation not possible (e.g. no internal weight). No second response follows.

Further Responses

C3_A	Adjustment has been completed successfully.
C3_I	The adjustment was aborted as, e.g. stability not attained or the procedure was aborted with the C key.

Comments

- Commands sent to the balance during the adjustment operation may not be processed and responded to in the appropriate manner until the adjustment is at an end.

Examples

↓	C3	Start internal adjustment.
↑	C3_B	Started.
↑	C3_A	Completed successfully.

I54 – External adjustment loads

Description

This command lists the available loads for external adjustment.

Syntax

Command

I54	Query list of adjustment methods.
-----	-----------------------------------

Responses

I54_A_«Min»_«Max»_«Increment»_«Unit»	Adjustment loads.
--------------------------------------	-------------------

Parameters / Return values

Name	Type	Values	Meaning
Min	float		Smallest load to use for external adjustment.
Max	float		Biggest load to use for external adjustment.
Increment	float		Load increment between Min and Max.
Unit	enum	see <i>Units</i>	Unit in which the previous values are given.

Examples

↓	I54	Query.
↑	I54_A_1000.0_3000.0_750.0_g	In the case of external adjustment, the loads for selection are 1000 g, 1750 g, 2500 g and 3000 g.

DM – Query / set display mode

Description

Describe the command in detail here.

Syntax

Command

DM	Describe different variants of the command in this table.
DM_«DisplayMode»	Describe different variants of the command in this table.

Responses

DM_A_«DisplayMode»	Current display mode.
DM_A	Display mode is set successfully.
DM_I	Command understood but currently not executable.
DM_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
DisplayMode	enum	DEF	Regular display mode.
		OFF	Display completely off (no segments)
		TXT	Display text defined in "D" only.

Comments

This command can be used (combined with κ), to disable the balance indication. Useful when only the remote indicator displays relevant/corrent information.

Examples

↓	DM	Query current display mode.
↑	DM_A_DEF	The current, stable ("S") weight value is 100.00 g
↓	DM_OFF	Switch display off.
↑	DM_A	OK, display switched off.
↓	DM_TXT DM_ "Hello World"	Set display to display text only, display "Hello World"
↑	DM_A	OK.

See also

→	D - Display text
---	------------------

PWR – Power on/off

Description

Switch device on, off or into standby.

Syntax

Command

PWR	Query current power state (if possible).
PWR_«On/Off»	Set current power state.

Responses

PWR_A	Device has been switched off successfully.
PWR_A I4_A_ "«SNR»"	Device has been switched on successfully. Serial number is sent after startup.
PWR_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
PWR_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
On/Off	integer	0	Switch to standby mode.
		1	Switch device on.
		2	Switch device off completely.

IBBS – Query battery status

Description

Query the current battery status.

Syntax

Command

IBBS	Retrieves the current battery capacity and charging status.
------	---

Responses

IBBS_A_«BatteryIndicator»_%_«ChargeStatus»	Current stable weight value in unit actually set under host unit
IBBS_I	No battery or no mechanism to retrieve battery charging status.

Parameters / Return values

Name	Type	Values	Meaning
BatteryIndicator	integer	0 - 100	Battery charge status in percent (how much battery capacity is left).
ChargeStatus	string	N	No external power, not charging, running from battery.
		C	Currently charging.
		F	Fully charged.

Comments

This command is mainly used for displaying a battery indicator in remote devices.

SENSL / SensorList – Query list of sensors in the device

Description

Lists the available sensors and basic information about each sensor.

Syntax

Command

SENSL	
-------	--

Responses

SENSL_B_«ID»_«Type»_«Description»_«CurrentValue»_«Unit»	
SENSL_B_«ID»_«Type»_«Description»_«CurrentValue»_«Unit»	
...	
SENSL_A_«ID»_«Type»_«Description»_«CurrentValue»_«Unit»	

Parameters / Return values

Name	Type	Values	Meaning
ID	int	0, 1, ...	Sensor unique ID
Type	string	T	Temperature sensor
		H	Relative humidity sensor
		P	Air pressure sensor
		BL	Bubble level status sensor (ok, not ok)
		BLPos	Bubble level position (X, Y)
		DL	Door limit switch
Description	string		Internal description of the sensor, e.g. LoadCellTemp, CaseTemp, EnvTemp, EnvHumi, EnvPres, BubbleLevelStatus, BubbleLevelPosition, DoorLimitSwitch
CurrentValue	float		Current value of the sensor
Unit	string		Unit of the value of the sensor

Examples

↓	SENSL	Send a list of the available sensors.
↑	SENSL_B_0_T_EnvTemp_22.00_°C SENSL_B_1_H_EnvHumi_50.00_% SENSL_B_2_P_EnvPres_106545.00_Pa SENSL_A_3_P_EnvPres_256512.00_Pa	The current available sensor list.

See also

➔	SENSI – Query detailed sensor information
➔	SENSQ – Query current sensor value

SENSI / *SensorInfo* – Query detailed sensor information.

Description

This command is not publicly documented.

SENSQ / SensorQuery – Query current sensor value.

Description

Use this command to query a specific sensor value.

Syntax

Command

SENSQ_«SensorID»	Query specific sensor value.
------------------	------------------------------

Responses

SENSQ_A_«SensorValue»_«Unit»	Current sensor value in unit actually set under host unit.
SENSQ_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
SENSQ_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
SensorID	integer	0, 1, 2, ...	Sensor ID
SensorValue	float		Sensor value
Unit	string		Currently displayed unit

Examples

↓	SENSQ_0	Send a sensor value from sensor 0
↑	SENSQ_A_22.00_°C	The current sensor value is 22.00 °C
↓	SENSQ_1	Send a sensor value from sensor 1
↑	SENSQ_A_50.00_%	The current sensor value is 50.00 %

See also

➔	SENSL – Query list of sensors in the device
➔	SENSI – Query detailed sensor information

IVERS – Query/set verification state

Description

Query or set current state of verification.

Syntax

Command

IVERS	Query current verification state.
IVERS_«VerificationState»	Set current verification state.

Responses

IVERS_A_«VerificationState»	Current verification state.
IVERS_A	Verification state set successfully.
IVERS_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).

Parameters / Return values

Name	Type	Values	Meaning
VerificationState	bool	0	not in verified mode
		1	in verified mode

IBIM – Query/set balance (brand) model number

Description

Set the balance brand model number (external article number for clients/sale).

Syntax

Command

IBIM	
IBIM_ "«ModelNumber»"	

Responses

IBIM_A_ "«ModelNumber»"	The brand model number.
IBIM_A	The brand model number is set successfully.
IBIM_I	Model number invalid (too short/long).

Parameters / Return values

Name	Type	Values	Meaning
ModelNumber	string		Brand model number (max. 31 characters).

Examples

↓	IBIM_ "IFB 30K-2M"	
↑	IBIM_A	

M19 – Query/set adjustment weight (with error)

Description

You can use M19 to set the currently used external adjustment weight, or to query the current weight setting.

Syntax

Command

M19	Query the current adjustment weight.
M19_«Value»_«Unit»	Set the adjustment weight.

Responses

M19_A_«Value»_«Unit»	Current adjustment weight.
M19_A	Command understood and executed successfully.
M19_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
M19_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
Value	float		Value of the adjustment weight, balance specific limitation
Unit	string		Lorem ipsum

Examples

↓	M19	Query current adjustment weight.
↑	M19_A_100.123_g	The current adjustment weight value is 100 g, with a deviation of 0.123 g.

See also

➔	I54 – Query adjustment loads
---	------------------------------

7 KCP commands for digital platforms

SJ/SJR – Send current indication with status

Description

Send current indication with additional information about the current status.

Syntax

Command

SJ	Send the current indication with status.
SJR[_«PauseMs»]	Send the current indication with status continuously. Optional pause between two SJ responses in milliseconds

Responses

SJR_«BM»_«WeightValue»_«Unit»	Current stable weight value in unit actually set under host unit with current status
SJR_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
SJR_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
PauseMs	integer		Pause between two SJ responses in continuous mode (SJ).
BM	char		Status coded in bit: 2 ⁰ = stable 2 ¹ = zero range 2 ² = tare 2 ⁵ = reserved 2 ⁶ = always 1
WeightValue	float		Weight value
Unit	string		Currently displayed unit

Examples

↓	SJ	Send the current indication with status.
↑	SJR_A_100.00_g	The current weight value is 100.00 g and status is zero range.
↓	SJ	Send the current indication with status.
↑	SJR_@_100.00_g	The current weight value is 100.00 g and status is stable.

JZ – Set zero adjustment

Description

Use JZ to set the zero adjustment of the balance.

Syntax

Command

JZ	Set zero offset of the balance.
----	---------------------------------

Responses

JZ_A	Zero offset setting successfully performed.
JZ_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
JZ_L	Command understood but not executable (incorrect parameter).

Examples

↓	JZ	Set zero offset of the balance.
↑	JZ_A	Zero offset setting successfully performed.

See also

➔	JG – Set gain adjustment
➔	JS – Save balance adjustment

JG – Set gain adjustment

Description

Use JG to set the gain adjustment of the balance.

Syntax

Command

JG	Set gain adjustment of the balance.
----	-------------------------------------

Responses

JG_A	Gain adjustment setting successfully performed.
JG_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
JG_L	Command understood but not executable (incorrect parameter).

Examples

↓	JG	Set gain adjustment of the balance.
↑	JG_A	Gain adjustment setting successfully performed.

See also

➔	JZ – Set zero adjustment
➔	JS – Save balance adjustment

JS – Save balance adjustment

Description

Use JS to save the balance adjustment settings in the permanent memory.

Syntax

Command

JS	Save the balance adjustment settings.
----	---------------------------------------

Responses

JS_A	Save balance adjustment settings successfully performed.
JS_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
JS_L	Command understood but not executable (incorrect parameter).

Examples

↓	JS	Save balance adjustment settings.
↑	JS_A	Balance adjustment settings successfully saved.

See also

➔	JZ – Set zero adjustment
➔	JG – Set gain adjustment

JNA – Query / set network address (IP)

Description

Use this command to query or set the network address (IP).

Syntax

Command

JNA	Query the current network address.
JNA_«NetworkAddress»	Set the current network address.
JNA_0.0.0.0	Activate DHCP.

Responses

JNA_«NetworkAddress»	Current network address (IP).
JNA_A	Network address setting successfully performed.
JNA_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
JNA_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
NetworkAddress	string		Network address (e.g. 192.168.0.1).

Examples

↓	JNA	Send current network address.
↑	JNA_192.168.0.1	The current network address is 192.168.0.1.
↓	JNA_192.168.0.1	Set network address to 192.168.0.1.
↑	JNA_A	Set network address setting successfully performed.
↓	JNA_0.0.0.0	Activate DHCP setting.
↑	JNA_A	Successfully activated DHCP setting.

See also

➔	JNK – Query / set network mask
➔	JNG – Query / set gateway address
➔	JNM – Query / set MAC address

JNK – Query / set network mask

Description

Use this command to query or set the network mask.

Syntax

Command

JNK	Query the current network mask.
JNK_«NetworkMask»	Set the current network mask.

Responses

JNK_«NetworkMask»	Current network mask.
JNK_A	Network mask setting successfully performed.
JNK_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
JNK_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
NetworkMask	string		Network mask (e.g. 255.255.255.0)

Examples

↓	JNK	Send current network mask.
↑	JNK_255.255.255.0	The current network mask is 255.255.255.0.
↓	JNK_255.255.255.0	Set network mask to 255.255.255.0.
↑	JNK_A	Set network mask setting successfully performed.

See also

➔	JNA - Query / set network address (IP)
➔	JNG - Query / set gateway address
➔	JNM - Query / set MAC address

JNG – Query / set gateway address

Description

Use this command to query or set the gateway address.

Syntax

Command

JNG	Query the current gateway address.
JNG_«GatewayAddress»	Set the current gateway address.

Responses

JNG_«GatewayAddress»	Current gateway address.
JNG_A	Gateway address setting successfully performed.
JNG_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
JNG_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
GatewayAddress	string		Gateway address (e.g. 192.168.0.99)

Examples

↓	JNG	Send current gateway address.
↑	JNG_192.168.0.99	The current gateway address is 192.168.0.99.
↓	JNG_192.168.0.99	Set gateway address to 192.168.0.99.
↑	JNG_A	Set gateway address setting successfully performed.

See also

➔	JNA – Query / set network address (IP)
➔	JNK – Query / set network mask
➔	JNM – Query / set MAC address

JNM – Query / set MAC address

Description

Use this command to query or set the MAC address.

Syntax

Command

JNM	Query the current MAC address.
JNM_«MACAddress»	Set the current MAC address.

Responses

JNM_«MACAddress»	Current MAC address.
JNM_A	MAC address setting successfully performed.
JNM_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
JNM_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
MACAddress	string		MAC address (e.g. 00:50:C2:E2:E0:00)

Examples

↓	JNM	Send current MAC address.
↑	JNM_00:50:C2:E2:E0:00	The current MAC address is 00:50:C2:E2:E0:00.
↓	JNM_00:50:C2:E2:E0:00	Set MAC address to 00:50:C2:E2:E0:00.
↑	JNM_A	Set MAC address setting successfully performed.

See also

➔	JNA - Query / set network address (IP)
➔	JNK - Query / set network mask
➔	JNG - Query / set gateway address

JDF – Query / set filter settings

Description

Use this command to query or set the filter settings.

Syntax

Command

JDF	Query the current filter settings.
JDF_«Filter»«Swap»	Set the current filter settings.

Responses

JDF_«Filter»«Swap»	Current filter settings.
JDF_A	Set filter setting successfully performed.
JDF_I	Command understood but currently not executable (device is currently executing another command, e.g. taring, or timeout as stability was not reached).
JDF_L	Command understood but not executable (incorrect parameter).

Parameters / Return values

Name	Type	Values	Meaning
Filter	float	0, 1, 2, 3, 4	Filter level (0 fast, 4 slow)
Swap	float	0, 1	Swap filter mode (immediate reaction to changes)

Examples

↓	JDF	Send the current filter settings.
↑	JDF_30	The current filter settings are 30.
↓	JDF_30	Set the current filter settings to 30.
↑	JDF_A	Set current filter settings successfully performed.

8 Command index

This page lists all the page numbers, relevant information to a command can be found.

				JNK	60		
@		I		JNM	62	T	
@	9	I0	10	JS	58	T	28
		I1	11			TA	29
C		I2	12	K		TAC	31
		I3	13			TAI	30
C3	44	I4	14	K	24	TI	32
		I5	15			TZ	41
D		I54	45	S			
		IBIS	14	S	4, 16	U	
D	22	IBMT	12	SI	4, 17	U	4, 33
DM	46	IBRL	42	SIM	4, 37		
DW	23	IBRT	43	SIR	18	Z	
		J		SJ	55		
E		JDF	63	SJR	55	Z	4, 19
		JG	57	SJMEM	4, 38	ZI	20
ETLS	39	JNA	59	SR	26		
		JNG	61				